

Bradas

INSTRUCTION

MECHANICAL WATER **TIMER** WL-3135







- 1 Battery compartment
- 2 Reduction for tap 3/4"
- Tap adapter 1'
- 4 Main button
- (5) Irrigation frequency
- 6 Irrigation time
- (7) Connector adapter
- 8 LED program indicator
- (9) Filter

BATTERY INSTALLATION

Press two buttons beside to open.



Remove battery compartment ① cover.



Insert 2 alkaline batteries 1.5V (LR03/AAA), put cover on and battery compartment in place again.

- 1. Use only new batteries at the begining of season. Do not use rechargeable batteries.
- 2. When batteries inserted, test timer by pressing button 4 to ON position and you should hear clicking sound within 10 seconds. If not, check if batteries are installed correctly.
- 3. If each of 14 LED lights blinks one by one with 0.5-second interval, insert new batteries.

TIMER INSTALLATION

For taps 3/4": install timer on tap using included reduction 3/4" 2.

For taps 1": remove reduction 3/4" ② and install timer directly on tap.

When timer installed on tap, attach hose and turn tap on.

- 1. Always keep filter 9 in place.
- 2. Set timer to OFF position before connecting to tap.

IRRIGATION FREQUENCY AND TIME SETTINGS

When new batteries are installed, all 14 LED lights flash once, valve closes and OFF position illuminate. Timer is ready to be set. Press button 4 repeatedly until desired irrigation cycle position and settings will be saved after 7 seconds.


First irrigation starts immediately when setting are confirmed.

Irrigation frequency: determines how often to water. Irrigation time: determines how long to water.


When making changes after initial settings: Settings are saved after 7 seconds without further pressing of button 4 . Led lights turns off within 60 seconds Changing LED position indicator changes irrigation start time and in this case next watering start time is recalculated again.

Frequency (hours)	Irrigation time (minutes)
12	2,7,15,30,45
24	5,15,30,60
48	15,30,60

EXAMPLE 1:To water 2 times a day for 15 minutes, press button 4 until LED light on position Frequency 12h/Irrigation time 15mins. Watering starts in 7 seconds.



EXAMPLE 2: To water 1 time a day for 30 minutes, press button 4 until LED light on position Frequency 24h/Irrigation time 30mins. Watering starts in 7 seconds...



IRRIGATION DELAY SETTINGS

EXAMPLE: Set time is 8:00am, frequency every 24 hours and irrigation time for 15 minutes (watering for 15 minutes every 24 hours starting at 8:00am everyday). If you want timer to start irrigation at 10:00am everyday (2 hours delay from current time 8:00am), press button 4 for 3 seconds until all LED lights are constantly on. Then press button 4 two times and timer starts irrigation at 10:00 every 24 hours.





Press button 4 for 3 seconds



All of LED lights are constantly on



Press X times, X means how many hours to delay (in this case 2 times)

MANUAL CONTROL SETTINGS

Press button 4 to ON position to start manual irrigation. Press button 4 to OFF position to stop manual irrigation. When all set, press button to another desired setting.

CARE AND MAINTENANCE

1. Only for outdoor use to control sprinklers and irrigation systems. Do not use for industrial purpose in contact with food products, chemicals and

- 2. Operating water pressure: 0,5 8 bar (7 116 psi).
- 3. Do not connect timer to tap with water pressure lower than 0,5 bar.
- 4. Operating water temperature: 0°C 60°C.
- 5. Protect timer during winter season and freezing conditions.
- 6. Timer is water-resistant, not waterproof.
- 7. Install timer above ground and vertically to tap.
- 8. Do not submerge in water and avoid timer to be in contact with water.
- 9. Do not pull hose once attached to timer to avoid any damage. 10. Filter traps dirt particles and prolongs life of
- timer. Clean filter regularly and replace when worn
- 11. Do not use spanners or pliers to avoid damage to timer.
- 12. If timer does not work, read instruction carefully again or contact your store service before returning timer to store.

MAINTENANCE

- 1. Close tap and remove timer.
- 2. Drain out water from timer.
- 3. Remove batteries.
- 4. Dry timer and store in dry indoor place.

















BRADAS Sp. z o.o. Sp.k ul. M. Konopnickiei 5 46-300 Olesno